

OVERVIEW

ART. 3117

3000 Series full base "4+1" and intercommunication audiophone incorporating an adjustable electronic call tone, "door open" push button and 4 additional buttons for intercommunicating.

For use on intercommunicating systems or traditional "4+1" audio systems that require an electronic call tone including the following audio kits: traditional VR audio systems, 4K series, 8K series, VR4K series and VR120DK series kits.

Call tone adjustment: 3 level (low, medium and high) call tone switch.

Additional buttons: 4 intercommunicating call buttons (numbered 1 - 4).



3117
3000 Series Audiophone
QUICK GUIDE



TECHNICAL SUPPORT
 Tel: 0191 224 3174
 Fax: 0191 224 4938
 Email: tech@videxuk.com
 Web: www.videxuk.com


06_3117_V1.0_08/17




ANSWERING A CALL (FROM THE OUT DOOR STATION)

beep!
beep!


During a call



1 To answer an incoming call pick up the handset.




2 With the handset lifted a conversation with the caller can begin.




3 To end the call replace the handset back on the cradle.


TO OPEN THE DOOR



During a conversation



1 During a conversation, with the handset lifted, press the lock button  to operate the lock.




2 To end the call replace the handset back on the cradle.


MAKING AN INTERCOMMUNICATING CALL (BETWEEN AUDIOPHONES)

zZz
zZz


In standby



1 Pick up the handset. Press the call button (1 - 4) for the required phone to be called.



2 When the phone which is called rings, it can be answered and a 2 way conversation between the caller and receiver can begin.




3 To end the call/conversation between the phones replace the handsets back on the cradle.

CALL TONE VOLUME ADJUSTMENT


zZz
zZz

In every situation



Move the volume switch to the lower position to set the call tone volume to low, to the middle position to set the call tone volume to medium and to the upper position to set the call tone volume to high.

TECHNICAL ADVICE



For further technical advice and assistance on the installation of this product please contact Videx technical on tel: 0191 224 3174.

For any sales advice and assistance please contact Videx sales on tel: 0191 238 8324.

To download a copy of this quick guide visit the Videx website: www.videxuk.com